

????????? TXT 4.0

????????? TXT 4.0 – ?? ???? ????? ???? ??????? ROBOTICS. ??? ????????? ????????????? ??????????? ??
 ?????????? ????????????? ??? ?????????.

??? ???????? ??? ?????? ?????????? TXT 4.0 ?????????? ?????????? ???'????, ?? ??? ??????
 ?????????? ??????. ?????????? ??? ??, ??? ??? ???? ?????? ????????????? ????? ?? ???'????, ? ??? ??????
 ???'???? ?? ????????? ? ?????????? ? ?????????????? ?????? ROBOTICS ?? ?? ????? fischertechnik.de.

??? ?????????? ?????????? ???????????? TXT 4.0 ? ???? ?????????? ??????

???, ?? ????????????? ????????????? ? ?????????? ??????????, ?? ???, ?? ????????????? ?????? ? ??? ?????????, ?????????? ? ?????????, ??? ??? ?????? ?????????? ? ?????????????? ?????????????? ROBO Pro Coding.

?????????? ?? ?????????? ??????????????

[illegible]

'??????' ????????

??? ?????????????? ?????????, ????? ?'????? ??? ? ?????'?????, ????????? ??? ?????????, ?? ?????
 ????????? ?????????? ????????? ROBO Pro Coding. ? ????????? ?????????? ?????????? ?'????????? ?????
 WLAN, ??? ????? Bluetooth, ??? ????? ??? USB.

'??????' ???? WLAN

1. ? ???????? ROBO Pro Coding ?????? ????????? ?????????? ?? ????????? ?????????, ??? ?????????? ?????? (???. ??????)
2. ??? ?????????? ?????? ?????? ????????? «WLAN AP»
3. ?'????????? ?????????? ?? ?????? ????????? WLAN
4. ? ????????????? ? ????????? Info (?????????????) -> WLAN ?????????? IP-???????? ?????????????? ?? ????????? ?? ?
????????? ?????? ?????? ?????????? ?? ????????? ??????????
5. ? ?????, ??? ?????? ????????? "API-Schlüssel", ?????????? ???? API (?????????? ?? ?????????????? ? ?????????
Einstellungen (?????????????????) -> API Schlüssel (????? API)
6. ???? ?????? ????????????? ?? verbinden (?'????????), ?????? ?????????????? ? ????????? ?????????? ?????? ?????????.
????????? ? ??? : ?????? ??????????????, ? ?????????? ?????????? ?????? ?????????? . ?????????, ??? ?? ???? ?????????
????????????????, ??? ????????? ?? ?????????????????.

Controller verbinden



IP-Adresse des Controllers *

192.168.9.2



API-Schlüssel *

5t9ojo

ABBRECHEN

VERBINDEN

?'???????? Bluetooth

1. ?'???????? ???? ???????? ? ?????????????? ????? Bluetooth (???????????????????? ???? Bluetooth ????'?????, ?????????? ??? ??????????)
- 2.??? ?????????? ?????? «Bluetooth» ?????????? IP-??????, ??? ? ??? ?'????????, ?????? ??????? ??????? ?? ??????
- 3.? ?????, ??? ????? ???????? "API-Schlüssel", ???????? ???? API (?????????? ?? ?????????????? ? ????????? Einstellungen (????????????????) -> API Schlüssel (????? API)
4. ????? ?????? ?????????? ?? verbinden (?'??????), ?????? ?????????????? ? ??????? ????????? ?????? ????????. ????????? ? ????: ?????? ??????????????, ? ??????? ?????????? ???? ????????. ???????, ??? ?? ???? ????????? ??????????????, ??? ??????? ?? ??????????????.

?'???????? ?????? ???? USB

1. ?'???????? ?????????? ?? ?????? ???????????, ????????????????????? ??????? USB
- 2.??? ?????????? ?????? «USB» ?????????? IP-??????, ??? ? ??? ?'????????, ?????? ??????? ??????? ?? ??????
- 3.? ?????, ??? ????? ???????? "API-Schlüssel", ?????????? ???? API (?????????? ?? ?????????????? ? ????????? Einstellungen (????????????????) -> API Schlüssel (????? API)
4. ????? ?????? ?????????? ?? verbinden (?'??????), ?????? ?????????????? ? ??????? ????????? ?????? ????????. ????????? ? ????: ?????? ??????????????, ? ??????? ?????????? ???? ????????. ???????, ??? ?? ???? ????????? ??????????????, ??? ??????? ?? ??????????????.

Revision #4

Created 14 June 2022 09:00:32 by Admin

Updated 23 June 2022 09:29:32 by Admin